

# **Quick Start Guide Appliance L-Type Supermicro**

**Version 1.2**

## Appliance L-Type Supermicro

Welcome to the SCION world! Here you can find initial connection instructions for your Anapaya L-type device to set it up as an EDGE appliance. When installing the appliance as a CORE appliance you may need to change the port assignment. Once the device is unpacked and installed in your rack environment, on the rear panel (depicted below) connect power both on port **A** and port **B**.



On the front panel of the device:

1. Plug the SFP28 transceiver into port **7** and connect the LAN access fiber optics to it.
2. Plug another SFP28 transceiver into port **8** and connect the WAN access fiber optics to it.
3. Optionally, connect port **1** to the management network (for BMC and OS Management)
4. For initial configuration either (1) connect a keyboard and a monitor, (2) use port **1**, or (3) connect a LAN cable to port **4** and the machine you want to configure the device from i.e. your laptop.
5. Turn the device on by pressing the power button **P**.

### Note

Your support may indicate other ports to connect the cables to. If, for example, RJ45 patch cables are used, port 5 will be the LAN port and port 6 the WAN port. Instead of transceivers and fibers, also DACs can be used (Direct Attached Cables).



After a few minutes, the system should have booted, and you should see a login prompt on the connected screen or you should be able to SSH into the device.

### Note

If you manually need to configure the device use the default credentials user: **anapaya** and password: **anapaya** to log in to the device through one of the following options:

1. The connected keyboard and a monitor.
2. Accessing the device via SSH using the DHCP assigned IP address or the static IP assigned to port 4 i.e. `ssh anapaya@169.254.1.1`. Make sure that on your computer you statically

configure the IP address **169.254.1.2/30** on the network interface the cable leading to the Appliance is connected to.

3. Once logged in, you can setup the WAN IP parameters as indicated by your support. For more information consult [docs.anapaya.net](https://docs.anapaya.net).
4. DHCP will be active on all ports, and port **4** will be assigned 169.254.1.1/30 until an appliance configuration is applied.

## Interface mapping

Interface Name	Port Nr. on Device	Port Usage	Port Type
eno1	1	BMC & OS Management	RJ45 1G
eno2	2	Unassigned	RJ45 1G
eno3	3	Unassigned	RJ45 1G
eno4	4	Unassigned	RJ45 1G
eno5	5	Default RJ45 LAN interface	RJ45 10G
eno6	6	Default RJ45 WAN interface	RJ45 10G
eno7	7	Default SFP28 LAN interface	SFP28 25G
eno8	8	Default SFP28 WAN interface	SFP28 25G
enp22s0f0	e0	Unassigned	SFP28 25G
enp22s0f1	e1	Unassigned	SFP28 25G
enp22s0f2	e2	Unassigned	SFP28 25G
enp22s0f3	e3	Unassigned	SFP28 25G

The official manual of the L-type hardware (SuperServer SYS-110D-8C-FRAN8TP) can be found at:

<https://www.supermicro.com/en/products/system/iot/1u/sys-110d-8c-fran8tp>

